

DMX-Kanalenoverzicht Versie 17-12-2023

Fixture	Kanalen	DMX Start	DMX Stop	LAMP-Mode	Locatie	Fixture (MA)	Dimmer	Shutter	Zoom	Rood	Groen	Blauw	Wit	Pan	Tilt	Pomp	Fan
Dimmer	1	1	1	1 CH (Dimmer)	Front 1	21	1										
Dimmer	1	2	2	1 CH (Dimmer)	Front 2	22	2										
Dimmer	1	3	3	1 CH (Dimmer)	Procenium L	23	3										
Dimmer	1	4	4	1 CH (Dimmer)	Procenium R	24	4										
Dimmer	1	5	5	1 CH (Dimmer)	Vloer L	25	5										
Dimmer	1	6	6	1 CH (Dimmer)	Vloer R	26	6										
Dimmer	1	7	7	1 CH (Dimmer)	Grid	27	7										
Dimmer	1	8	8	1 CH (Dimmer)	Grid	28	8										
Dimmer	1	9	9	1 CH (Dimmer)	Grid	29	9										
Dimmer	1	10	10	1 CH (Dimmer)	Grid	30	10										
Dimmer	1	11	11	1 CH (Dimmer)	Inloop vloerspots	9	11										
Dimmer	1	12	12	1 CH (Dimmer)	Zaalverlichting	10	12										
TF-300	1	101	101	1 CH (Dimmer)	Front L	1	101										
TF-300	1	102	102	1 CH (Dimmer)	Front LM	2	102										
TF-300	1	103	103	1 CH (Dimmer)	Front RM	3	103										
TF-300	1	104	104	1 CH (Dimmer)	Front R	4	104										
TF-300	1	105	105	1 CH (Dimmer)	Procenium L	11	105										
TF-300	1	106	106	1 CH (Dimmer)	Procenium R	12	106										
TS-260C7	10	111	120	10 CH (RGB-Pro)	Front L	5	111	113		115	116	117					
TS-260C7	10	121	130	10 CH (RGB-Pro)	Front LM	6	121	123		125	126	127					
TS-260C7	10	131	140	10 CH (RGB-Pro)	Front RM	7	131	133		135	136	137					
TS-260C7	10	141	150	10 CH (RGB-Pro)	Front R	8	141	143		145	146	147					
TS-260C7	10	151	160	10 CH (RGB-Pro)	Hok	141	151	153		155	156	157					
TS-260C7	10	161	170	10 CH (RGB-Pro)	Hok	142	161	163		165	166	167					
TS-260C7	10	171	180	10 CH (RGB-Pro)	Hok	143	171	173		175	176	177					
TS-260C7	10	181	190	10 CH (RGB-Pro)	Hok	144	181	183		185	186	187					
Focus Flex	25	250	274	25 CH (Standaard)	Tegen L	101	264	263	266	254	255	256	257	250	252		
Focus Flex	25	275	299	25 CH (Standaard)	Tegen LM	102	289	288	291	279	280	281	282	275	277		
Focus Flex	25	300	324	25 CH (Standaard)	Tegen RM	103	314	313	316	304	305	306	307	300	302		
Focus Flex	25	325	349	25 CH (Standaard)	Tegen R	104	339	338	341	329	330	331	332	325	327		
Focus Flex	25	350	374	25 CH (Standaard)	2e-Plan LMV	111	364	363	366	354	355	356	357	350	352		
Focus Flex	25	375	399	25 CH (Standaard)	2e-Plan RMV	112	389	388	391	379	380	381	382	375	377		
Focus Flex	25	400	424	25 CH (Standaard)	Zij LA	121	414	413	416	404	405	406	407	400	402		
Focus Flex	25	425	449	25 CH (Standaard)	Zij RA	122	439	438	441	429	430	431	432	425	427		
Focus Flex	25	450	474	25 CH (Standaard)	Zij LV	131	464	463	466	454	455	456	457	450	452		
Focus Flex	25	475	499	25 CH (Standaard)	Zij RV	132	489	488	491	479	480	481	482	475	477		
Unique 2.1	2	511	512	2CH Hazer	Hok	200										511	512

Unassigned adressess	Start	Stop	Available DMX CH
	25	100	76
	191	249	59
	500	510	11
TS-260C7 (Indien niet gepached)	151	190	40